HUAYU (English)

RM-L1130+X PLUS
Instruction for UNIVERSAL LCD/LED TV REMOTE CONTROLLER

Thank you for using our company remote controller products. When it is the first time to put in the batteries, please try it first. If it could work well with all of its functions, the product can be used directly without setup. If it could not work well, it should be set with the following methods before controlling your TV. This remote controller would not lose its memory when you change batteries, no need to reset.

Introduction

RM-L1130+X PLUS is the newest universal LCD/LED TV remote controller. Comprehensive care at different levels need, it can control old or new TV, famous brand or un-famous brand TV, nearly all models for TV.Commonly used functions and menu functions, learning, easy setup, conveniently use, it is the best choice for your remote controller.losing, damage, replacement, it will bring more convenient for your life.

Battery Installation

In accordance with the "+,-" symbols which is indicated inside the battery cabinet, open the cover and put into two new AAA (AAA) batteries (non-rationed), which is shown in the figure.

Battery Description

- The remote controller is a low-power consume product. The lifetime of batteries is about 12 months under normal circumstances. If it is improperly used or operated, the lifetime would be shortened.
- Please do not put old and new batteries or different types of batteries together.
- In case of battery leakage, the batteries must be removed and the battery cabinet should be cleaned before putting into new batteries.
- You'd better remove the batteries from the battery cabinet if you intend to stop using the remote controller for a long time.

Methods for setting remote controller:

This remote controller has the following methods for setup , you can choose any of them.

****

A.Inputting code:

1.Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV. Find the three digits code from the code list.

2.Press "SET" button, then press "POWER" button, till the indicator lamp lights, then release the buttons, the remote controller will be in the state of inputting code.

3.Enter the first set of three-digit code in order. When you input each digit, the indicator lamp will flash one time, when you enter all of the three digits, the indicator lamp will turn off , setting to be finished. If the code is more than one set, please use first one at first.

4.Test other function buttons can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

B.Manually searching for the code:

1.Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV.

2.Press "SET" button, then press "POWER" button, till the indicator lamp lights, then release the button, the remote controller will be in the state of Manually searching for the code.

3.Press the "VOLUME+" button one time, the indicator lamp will flash one time, please pay attention to your TV, see the volume symbol appears on your TV or not, if not, please repeat this procedure.

4.Till the volume symbol appears on your TV, test other function buttons (except SET, POWER, and VOLUME button) can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

C.Automatically searching code:

1. Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV.

2. Press and hold the "SET"button for about 6 seconds, till the indicator lamp lights, the remote controller will enter automatic search state,please pay attention to your TV, see the volume symbol appears on your TV or not, if yes, please release "SET" button at once, set finished.

3. Test other function buttons (except SET, POWER, and VOLUME button) can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

D.Point to Point Brand Searching:

1. Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV. Find out the corresponding brand of your TV on this remote control, for example, Telefunken = "0"

2. Press and hold the corresponding brand button for three seconds, the indicator lamp will flash, when the volume symbol appears on your TV, release button at once, the indicator lamp will turn off, set to be finished.

E.Restore factory Settings

Press "SET" button, then press "0", release the button, the indicator will flash two times, the remote controller restore factory Settings

Brand symbol table

HAIER	GRUNDIG	SONY	LG	SAMSUNG	SANYO	TCL	PHILIPS	NEC	SHARP	ROTEL	ONKYO	PIONEER	YAMAHA
ONKYO	JVC	SANYO	KEYO	Mitsubishi	SANYO	SANYO	JVC	JVC	CLATRONIC				
PHILIPS	TCL	NEC	SHARP	ROTEL	ONKYO	PIONEER	YAMAHA						
SONY	SONY	PHILIPS	ONKYO	YAMAHA	SONY	PIONEER	YAMAHA						
SONY	SONY	PHILIPS	ONKYO	YAMAHA	SONY	PIONEER	YAMAHA						

B0064480

HUAYU® **RM-L1130+X PLUS**

| | | |

HUAYU® RM-L1130+X PLUS

| | | |

HUAYU® **RM-L1130+X PLUS**

| | | |