



"LG/Samsung/Sony" Button

TV/RADIO
I/⏻
DIGITAL/ANALOG
3D
LIST
FAV
PRE-CH
MEDIA
APP/*
HOME
MENU
BACK
EXIT
VOL+
VOL-
MUTE
INFO
P/CH ^
P/CH v
RED/A
GREEN/B
YELLOW/C
BLUE/D
1
2
3
4
5
6
7
8
9
0
LIST
MY APPS
AUDIO
SUBT.
Q.MENU
S.MODE
SEARCH
TOOLS
P.MODE
RECENT

"SONY" Function

TV/RADIO
I/⏻
DIGITAL/ANALOG
3D
TITLE LIST
FAV/MARK
Q.VIEW
O/AV MODE
REC/*
LIVE TV
APP/*
HOME/SMART
OPTIONS
OK
RETURN
EXIT
VOL+
VOL-
MUTE
i+?
PROG+
PROG-
RED
GREEN
YELLOW
BLUE
1
2
3
4
5
6
7
8
9
GUIDE
SEN/APPS
AUDIO
DISCOVER
SCENE
RELATED SEARCH
SYNC MENU
THEATRE
i-MANUAL/?

"LG" Function

TV/RAD.
INPUT
AD/PIP*
RATIO
3D
LIST
FAV/MARK
Q.VIEW
O/AV MODE
REC/*
LIVE TV
APP/*
HOME/SMART
SETTINGS/Q.MENU
OK/ENTER
BACK/RETURN
EXIT
VOL+
VOL-
MUTE
i/INFO
P/PAG ^
P/PAG v
RED
GREEN
YELLOW
BLUE
1
2
3
4
5
6
7
8
9
GUIDE
TEXT
MY APPS
ENERGY SAVING
SUBTITLE
Q.MENU/SUBTITLE/3D OPTION
TV/PC
NETCAST
T.OPT.
SIMPLINK
RECENT

"SAMSUNG" Function

TV
SOURCE
AD
P.SIZE
3D
CH.LIST
FAV.CH.
PRE-CH.
MEDIA.P.
STATUS
SMART HUB/CONTENT
MENU
OK
BACK/RETURN
EXIT
VOL+
VOL-
MUTE
i/INFO
P/PROG./CH ^
P/PROG./CH v
RED/A
GREEN/B
YELLOW/C
BLUE/D
1
2
3
4
5
6
7
8
9
GUIDE
TTX/MIX
FAMILY STORY
DUAL/I/II
AD/SUBT.
D.MENU
S.MODE
SEARCH
TOOLS
P.MODE
HISTORY