HUAYU® RM-B599

RM-B599 USE FOR SATELLITE RECEIVER. Please use this product on a trial basis immediately after in stalling the batteries for the first time.if every function works properly, enjoy your use without doing any Settings;otherwise,you have to employ the following method to do some settings. No need to do settings on the chips: BIG SAT/ACH-P-2/BERICCO-M007/EL-41/Gold General/EUROBOX/SR-C2/SR-X1200D/IPM/DYNASAT NUMBER1/SAT80200 (14169)/SAT RC(10362)/ECHOLINK/STAR-X,

Model select

Press the "⏻" key and "NUMBER" key at the same time, after that release them. The setting is complete.

Automatic searching

Hold the"⏻"key (about 6 seconds). The remote controller enters automatic searching mode. When the volume symbol is displayed; release" ⏻ "key to save and exit.

⏻ +0

ANHUI HUAYU ELECTRONIC TECHNOLOGY CO., LTD.

HTTP://www.huayu.cc